# Instrument Cleaning Care FRENCH HORN

Online Video at: www.rockymountainmusicrepair.com/instrument-care

#### Daily

- Oil rotors before and after playing.
- Pull slides and empty water, carefully rotate horn counterclockwise to empty remaining water.

#### Weekly

- Wash mouthpiece with a brass mouthpiece brush and warm soapy water.
- Clean slides and re-grease with slide grease.
- Wipe fingerprints off with a soft cloth and Pledge furniture polish.
- Vacuum case to get rid of all debris.

# **Every Other Month**

• Give your instrument a bath. (See reverse side)

# Yearly

• Bring your instrument to a qualified repair technician for a professional rotor alignment, rotor retie and deep clean.

### **Cleaning Supplies Needed**

 Valve Oil, Slide Grease, Brass Mouthpiece Brush, French Horn Snake, Trumpet Rod, Soft Cloth, Pledge Furniture Polish.



# **GIVING YOUR HORN A BATH**

(French Horn)

#### Prep

- 1. Place an old towel on the bottom of your bathtub, run luke-warm water with Dawn dish soap and fill bath so that the water will cover the slides (about 2 inches of water).
- 2. Remove all slides from the instrument and carefully place on towel in the bath.
- 3. DO NOT DISASSEMBLE THE ROTORS! (this will be cleaned by a professional repair shop during the yearly deep cleaning).
- 4. Let the slides soak for 30 minutes.

#### Clean

- 5. Use your snake to scrub out the insides of the slides.
- 6. Use your snake to scrub out the leadpipe section of the horn. Be very careful to not get any other parts of the French horn wet (as much as possible).
- 7. Rinse everything with leadpipe and slides with clear water.
- 8. Let dry overnight.

#### Reassemble

- 9. Use the cleaning rod with a soft cloth to remove any residual oil from the slides and tubes (including tubes on the body of the horn).
- 10. Oil rotors valves with valve oil. Depress rotor paddle half way, drip valve oil into corresponding slide tube, then work oil into rotors by pressing the paddle multiple times.
- 11. Grease slides with slide grease and reinsert into horn.
- 12. Clean fingerprints and water marks from the outside with a clean cloth and Pledge furniture polish.