Instrument Cleaning Care **DOUBLE REEDS**

Online Video at: www.rockymountainmusicrepair.com/instrument-care

Daily

- Remove water from inside of the oboe/bassoon with a drop swab.
 (If it ever gets stuck, take it to a repair shop right away, don't try pulling on it harder).
- Store reeds in reed holder or case, NEVER on instrument.

Weekly

- Gently remove finger prints from the keys with soft cloth.
- Clean & grease all tenon corks with a dab of new cork grease.
- Vacuum case to get rid of all debris.

Yearly

• Bring your instrument to a qualified repair technician for a professional regulation & lubrication and to replace needed pads.

Cleaning Supplies Needed

Oboe or Bassoon Drop Swab, Soft Cloth, Cork Grease



